

SF Asennusohje
 S Installation instruktioner
 N Installationsinstruktioner
 DK Installationsinstruktus
 NL Installatievoorschrift
 D Montageanweisung
 F Instructions d'installation
 ES Instrucciones de montaje
 I Istruzioni di montaggio

M41A15

ASENNUSOHJE/ INSTALLATION INSTRUCTIONS

A1-A5

A1

A2

A3

A4

A5

Wiring diagram details:

- Terminal 3: Y
- Terminal 2: 24 V.L
- Terminal 1: 24 V.~
- Control: 0(2)...10 Vdc Y
- Control: 0% - 100% 24 V.L
- Control: 24 V.~
- W2: 2...10 V 0...10 V
- W1: 10 V

